

SqR™

Compact End Face Cleaning Tool

PRODUCT DESCRIPTION

SqR™ is the precision wipe system employing a patented process for cleaning fiber optic end-faces. It is a self-contained cleaning tool that can be used in the wet-to-dry combination cleaning process CCp™. The SqR™ is portable, convenient and economical for use in field or in tools kits.

- The folds and packaging material of the SqR™ provides surface for cleaning and complete instructions and guides.
- Effective wet-to-dry cleaning
- Provides an ideal Cleaning System for field or OEM applications
- Convenient Size - Portable system easily fits in tool cases and is handy to use on work benches. Easily slides into a pocket too.
- Heavy duty lint-free wiping material tough-enough to remove buffer-gel; soft enough for all end face cleaning
- Wipe material won't shred or tear

TYPICAL APPLICATIONS

SqR™ wipes are used in Fiber Optic and Telecommunications applications for:

- End-Face Connector Cleaning
- Splice Preparation
- Buffer Gel Removal

TYPICAL PRODUCT DATA AND PHYSICAL PROPERTIES

SqR™ wipes are 100% noncontaminating material. These wipes have high absorbency and contamination entrapment capacity, as well as high wet strength.

- Excellent solvent resistance
- Excellent particle entrapment
- High absorbency capacity and rate
- Very low solvent extractables
- High wet strength

COMPATIBILITY

SqR™ wipes are compatible with most common solvents such as alcohols, hydrocarbons and chlorinated solvents. The wipes are also generally compatible with dilute or weak acids.

TECHNICAL AND APPLICATION ASSISTANCE

Chemtronics provides a technical hotline to answer your technical and application related questions. The toll free number is: **1-800-TECH-401.**

AVAILABILITY

SqR™ Wipes 4" x 4" 10 wipes/unit




USAGE INSTRUCTIONS

Wet-to-dry Cleaning with the SqR™

1. Place the barrier with the guiding arrows between the top and second wipe.
2. Lightly spot the SqR™ wipe on with Electro-Wash® PX, Electro-Wash® MX pen or Fiber-Wash™
3. Draw the end-face from the solvent wetted area to the dry area; following the arrows visible through the wipe
4. Repeat two more times.

For Splice Preparation

1. Remove the top wipe from the SqR™ pad of wipes
2. Lightly moisten the SqR™ wipe with Electro-Wash® PX, Electro-Wash® MX pen or Fiber-Wash™
3. Gently wipe away fiber contaminants.
4. Lightly dampen a 38540ESD swab, remove soil from V-grooves on fusion splicer.



Buffer Gel Removal

1. Pull three single SqR™ wipes from the SqR™ pad of wipes
2. Lightly moisten the SqR™ wipe with Electro-Wash® PX, Electro-Wash® MX pen or Fiber-Wash™
3. Pull the cable through the first wiper and discard.
4. Repeat with the other two wipes until the cable 'squeaks' clean.

CHEMTRONICS

8125 Cobb Center Drive
Kennesaw, GA 30152

1-770-424-4888 REV. B (08/13)

www.chemtronics.com

NOTE: This information is believed to be accurate. It is intended for professional end users having the skills to evaluate and use the data properly. Chemtronics does not guarantee the accuracy of the data and assumes no liability in connection with damages incurred while using it.

Chemtronics Electro-Wash® is a registered trademarks of Chemtronics. All rights reserved. SqR™, CCp™, and Fiber-Wash™ are trademarks of ITW Chemtronics. All rights reserved.

DISTRIBUTED BY: